



## SITE CHOICE









SMRITIVAN EARTHQUAKE MEMORIAL MUSEUM, BHUJ



SMRITIVAN EARTHQUAKE MEMORIAL MUSEUM, BHUJ



SMRITIVAN EARTHQUAKE MEMORIAL MUSEUM, BHUJ



SMRITI VAN EARTHQUAKE MEMORIAL MUSEUM, BHUJ

## **MUSEUM PLINTH LEVELS** +136.400 +127.400 +119:300 +115.700 +112.100 nnnn 106.700 +101.100

